

# ICOM INSTRUCTIONS

## DESKTOP MICROPHONE

# SM-6

Thank you for purchasing the **SM-6** DESKTOP MICROPHONE.

The **SM-6** is designed for base station operation with an Icom transceiver. The **SM-6** provides high-quality audio and a flexible, free-bending neck for your convenient operations.


### PRE-OPERATION

1. Set the mic gain control located on the bottom of the microphone to the center position.
2. Connect the connector plug to the transceiver mic connector.
3. Keep the soft sponge on the mic element during operations.

### OPERATION

1. Push and hold the PTT switch to transmit and release to receive.
2. For continuous transmission, use the PTT lock function:
  - Push the PTT switch and then pull it backwards until "LOCK" appears.
  - Push the switch forward to release the lock.
3. Adjust the mic gain control, if desired.

### SCHEMATIC DIAGRAM



Icom Inc.

6-9-16, Kamihigashi, Hirano-ku, Osaka 547, Japan

Count on us!

A-8062S-1EX Printed in Japan  
Copyright © 1989 by Icom Inc.